




YELLOW CRANE TOWER(Large) HP237



CP-ASSY-HP237#-A1-20220217

Installation Reminder

- Prepare tools:




It is recommended to use piececool authentic assembly tools to build or fix the design. It is tailor made for the metal pieces and user friendly.

WARNING – Please handle metal sheets with care. The parts may have sharp edges that could cut or scratch skin. Keep away from children.


• Installation Method:

a. Remove the parts




Please use the clipper to cut the nozzle position and remove the parts.

d. Retaining the parts




Insert the hole, bending tab with angle 90°

b. Identify the parts



Identify the insert tab, fold line and the insert hole.

c. Folding the parts



Please use the needle nose pliers to fold the cutting parts into models.

• Attention:

E Engraved / Color side

NE Non-engraved / Silver side

! Attention Point


| Keep the parts symmetrical

When cutting metal parts, please do not cut the "insert tab" as "nozzle position". Only cut the parts of the current step when cutting the parts. Do not cut all the parts at one time to avoid loss.


When encountering the parts of the folding line, please pay attention to the front and back of the metal sheet and the direction of the folding. According to the direction indicated in the instruction, cut lightly and fold slowly. It is best to fold it once. Do not fold it repeatedly to avoid damage to the parts.

Assembly Guide


Step 01




Step 02




Step 03




Step 04




Step 05




Step 06




Step 07




Step 08




Step 09




Step 10




Step 11




Step 12



Step 13



Step 14



Step 15

CEF-21 x10

F-22 x3

Step 14 x2

F-23 x4

Step 16

B-24 x1

Step 15 x2

E

Step 17

B-25 x1

Step 15 x2

E

Step 18

B-26 x1

E

Step 19

CEF-21 x6

F-22 x3

Step 18 x2

F-23 x2

Step 20

B-27 x1

Step 19 x2

E

Step 21

B-28 x1

Step 19 x2

E

Step 27

Step 26 x2

Step 25 x2

Step 28

C-36 x4

E

Step 29

Step 28 x2

Step 27 x2

Step 30

E-38 x2

D-39 x2

C-37 x2

E

Step 31

C-40 x2

E-38 x2

D-39 x2

E

Step 32

Step 31 x2

Step 30 x2

Step 22

Step 21 x2

Step 17 x2

Step 16 x2

Step 20 x2

Step 23

Step 22 x2

Step 13 x2

Step 24

D-30 x2

C-31 x2

E-29 x2

E

Step 25

E-32 x4

Step 24 x2

E

Step 26

D-34 x2

E

D-33 x2

E-35 x2

E

Step 33

Step 29 x2

Step 32 x2

Step 34

B-41 x2

BC-42 x2

D-43 x2

E

Step 35

B-44 x2

BC-42 x2

D-43 x2

E

Step 36

Step 35 x2

Step 34 x2

Step 37
















A-45 x4

E






Step 38












C-46 x2

E











9 10
11 12






13 14
15 16




Step 80




Step 81




Step 82




Step 83




Step 84



Step 85




Step 86




Step 87



Step 88



Step 90



Step 89

